

TABLE OF CONTENTS

| | | |
|----------|-------------------------------|--|
| 1 | Before driving | Information on the hybrid system and adjusting and operating features such as door locks, mirrors, and steering column |
| 2 | When driving | Driving, stopping and safe-driving information |
| 3 | Interior features | Air conditioning and audio systems, as well as other interior features for a comfortable driving experience |
| 4 | Maintenance and care | Cleaning and protecting your vehicle, performing do-it-yourself maintenance, and maintenance information |
| 5 | When trouble arises | What to do if the vehicle needs to be towed, gets a flat tire, or is involved in an accident |
| 6 | Vehicle specifications | Detailed vehicle information |
| 7 | For owners | Reporting safety defects for U.S. owners and seat belt instructions for Canadian owners |
| | Index | Alphabetical listing of information contained in this manual |